


CARTA DELL'ESPOSIZIONE DEI VERSANTI PARTE NORD DEL COMUNE

SCALA 1:18.000



Legenda:

-  Limite confine comunale
-  North (0-22.5, 337.5-360)
-  Northeast (22.5-67.5)
-  East (67.5-112.5)
-  Southeast (112.5-157.5)
-  South (157.5-202.5)
-  Southwest (202.5-247.5)
-  West (247.5-292.5)
-  Northwest (292.5-337.5)