


CARTA DELL'ESPOSIZIONE DEI VERSANTI PARTE SUD DEL COMUNE

SCALA 1:18.000



Legenda:

	Limite confine comunale
	North (0-22.5,337.5-360)
	Northeast (22.5-67.5)
	East (67.5-112.5)
	Southeast (112.5-157.5)
	South (157.5-202.5)
	Southwest (202.5-247.5)
	West (247.5-292.5)
	Northwest (292.5-337.5)